

IKEA ANTILOP


Cover FABRIC SUPPORT PILLOW


Kelseybarg.com



We recommend printing at 100% scale setting on your printer. Some lines may be lost in your printer margins, however placing each paper flush with its neighbor will keep the correct pattern size/scale. Example above printed on a margin-less printer. Printers with margins will have gaps between the lines from page to page, no need to make them touch.







18 INCH ZIPPER

